# Commonly used parts for your

# Mod.917. 388191 CRAFTSMAN MOWER

| Description | Part # | Stock # |
|---|---|---|
| Blade | P/N 406712 | 33275/33277 |
| Spark Plug | P/N RJ19LM | 85858 |
| Air Filter | P/N 698269 | |
| Grass Bag | P/N 408955 | |
| Wheel Rear | P/N 194348X427 | |
| Wheel Front | P/N 194345X427 | |
| Zone Cable | P/N 176556 | |
| Owners Manual | P/N 423055 | |
| Engine Oil | | 33000 |

Parts available at most Sears Retail Stores
or for parts delivered to your home, Call
1-800-366 PART or go online at Sears.com

CAUTION : Read and follow all Safety Rules
and Instructions in your Owners Manual
before Servicing or operating this equipment